

90si User's Guide Addendum for the Model 690 Secure Fax System (MFC-8480DN and 90si)



MEMORY NOTE: The memory battery has been removed from your MFC-8480DN. When the power goes out or the unit is turned off any image data in memory will be lost/erased.

Set up your MFC-8480DN and your 90si per the directions in the **Easy-Fax 90si Secure Facsimile Gateway User's Guide** detailed in **Section 2.0 Installation**.

MFC-8480DN Settings

Check (and change as required) the following three settings on your fax.

Setting MFC-8480DN to Fax Only

Your fax should come from the factory pre-set to Fax Only. If not:

1. Press **Menu, 0, 1**.
2. Press **▲** or **▼** to select **Fax Only**. Press **OK**.
3. Press **Stop/Exit**. The LCD will now display **Fax Only**

Setting MFC-8480DN to Basic Compatibility (cuts the modem speed to 9600 bps. max)

Your fax comes from the factory set to **High**. To set it so **Basic**:

1. Press **Menu, 2, 0, 1**.
2. Press **▼** to select **Basic**. Press **OK**.
3. Press **Stop/Exit** to return to the standby display.

continued...



**GateWay
Fax
Systems, Inc.**

GateWay Fax Systems, Inc.
Virginia, USA
Toll Free: 1-877-951-9800
Tel: 804-796-1900, Fax: 804-796-1116
Web: <http://www.gwfs.com>
Email: info@gwfs.com

Setting the MFC-8480DN Ring Delay to 0

Your fax should come from the factory set to answer on 3 rings. Use the following procedure to change it to 0 (zero). This will cause your fax to answer immediately.

1. Make sure you are in Fax mode by pressing the **Fax** button under the LCD display.
2. Press **Menu, 2, 1, 1**, and the LCD will say **21. Setup Receive / 1.Ring Delay / 03 / 04 ...**
3. Press **▲** or **▼** to select **00**. Press **OK**.
4. Press **Stop/Exit**.

90si User's Guide Changes

The following 90si User's Guide sections, 3.3 and 3.4, have been modified specifically for the MFC-8480DN. All other sections of the 90si User's and Reference Guides' remain unchanged.

3.3 Sending a Secure Facsimile

1. Place a call on your Secure Telephone.
2. Place your Secure Telephone in Secure Data mode.
3. Load your document on MFC-8480DN (Face UP).
4. Make sure the MFC-8480DN is in "Fax" mode. Press "Fax" under the display.
5. On the MFC-8480DN press: "Hook", "1" (on the dial pad) and "START."
6. Standby while the document is sent. When finished, the fax will beep once and briefly display "Completed." It is now OK to return to secure voice mode or hang up the call.

3.4 Receiving a Secure Facsimile

Note: Insure that your MFC-8480DN has "Fax Only" in the display when idle. This indicates that the fax is in Auto-Receive mode. If it does not, see "Setting MFC-8480DN to Fax Only" above.

1. Answer your Secure Telephone.
2. Place your Secure Telephone in Secure Data mode. The sender usually initiates this.
3. Standby, the fax will be received automatically.

Technical Support

You get Free, Unlimited, Lifetime, STE equipped, Technical Support with your purchase. Feel free to contact me for any reason...or you may call our STE Test Line.

Secure Fax Test Line

You may also test your system or any of those in your secure fax network with our Secure Fax Test Line. Test, troubleshoot or simply practice, as much as you wish, from 9AM to 6PM EST, Monday through Friday. We are equipped with STU-III's and will get your equipment operational quickly. Please call toll-free: 1-877-951-9814 or 336-697-9100.



**GateWay
Fax
Systems, Inc.**

GateWay Fax Systems, Inc.
Virginia, USA
Toll Free: 1-877-951-9800
Tel: 804-796-1900, Fax: 804-796-1116
Web: <http://www.gwfs.com>
Email: info@gwfs.com